



THIS IS CONFIDENTIAL INFORMATION.
THIS DRAWING AND DESIGN IS THE PROPERTY OF LIQUIP INTERNATIONAL PTY LIMITED.
IT MUST NOT BE COPIED OR REPRODUCED IN ANY WAY WHATSOEVER AND/OR PASSED ON
TO ANY THIRD PARTY WITHOUT WRITTEN AUTHORITY.

LIQUIP INTERNATIONAL PTY LIMITED - ENGINEERING DEPARTMENT - 13 HUME RD SMITHFIELD SYDNEY NSW AUSTRALIA 2164
PH: +61 2 9725 9000 FAX: +61 2 9609 4739 EMAIL: engineering@liquip-nsw.com.au

Fitting DIP310-1 Aluminium Mounting Pad for Diptronic Sensor

Refer to the 7329 Diptronic Installation Manual.

- Choose location for Diptronic sensor mounting pad so that it is in the centre of the compartment.
- Mark out & cut a hole in this position 130mm in diameter.
- Tack weld the DIP310-1 mounting flange into the hole so the top surface is parallel to the longitudinal axis of the tanker, i.e. the Diptronic stick must be mounted perpendicular to the tanker axis. Position the top of the circular section approx 6mm above the walkway.
- Fully seal weld all around.

